

## Moto Guzzi Super Alce Wiring Diagram

1.	Dynamo charge indicator light (6V 3W)
2.	Key switch *
3.	Fuse
4.	4B: Terminal board – back 4F: Terminal board – front
5.	City light (6V 5W 38 mm)
6.	Head light high/low beam (6V 25/25W)
7.	Head light switch (high/low)
8.	Dynamo (case earthed)
9.	Battery (6V 10 AH)
10.	Tail light (6V 3W)
11.	Horn
12.	Horn button
13.	Stop light switch
14.	Stop light
15.	Head light shell

Wire Size and Length	
# 51	1.5 mm x 1.35 meters
Ø +	1.5 mm x 1.10 meters
FT	1.0 mm x 2.30 meters
# 61	1.0 mm x 1.35 meters
T + T -	1.5 mm x 1.45 meters
Cable sheath	11.0 mm x 0.5 meters

\* Insert key: Horn + generator light  
 Insert and turn key: Above plus head light and tail light.  
 Generator light goes off above 1,000 rpm

